

# QUICK EXHAUST WITH COMPRESSION CHAMBER

Quick exhausts with compression chambers are located on **transfer arms** and on **transport units**.

They are composed of:

- two hoses,
- a flow control valve,
- a plug with a small hole.

They act as external end of stroke cushions for clamps cylinders.

It is very important to replace them by original parts, as hoses diameters and lengths are determining.

